



Firemaster Wildland

Wildland Fire-fighting Glove, Style No: SB02417A

DESCRIPTION and USE

Firemaster Wildland is an entry level EN659 accredited glove that offers superior protection at an affordable price. The style has a PYROHIDE cowhide leather palm and a NOMEX® Delta TA fabric back made from 75% Nomex (Meta aramid), 23% Kevlar (Para aramid) and 2% Antistatic fibres. The outer shell is finished with NOMEX®/KEVLAR® knitted wristlet cuff. Inside there is an internal KEVLAR® cut resistant patch across the knuckles to provide increased protection from cuts and radiant heat. The style is lined with a seamless knitted lining made from a single ply KEVLAR® yarn with a glass-fibre core which offers exceptional levels of cut resistance as well as active perspiration technology through the Viloft yarn that is plated to the face of this lining. The glove is designed to offer the wearer a high degree dexterity as well as protection during wildland and structural fire-fighting duties.

LEATHER SPECIFICATIONS



PYROHIDE is a world class top-grade grain cowhide leather developed and manufactured in the UK specifically for fire-fighters. It offers resistance to fire, heat,

water, salt water, liquid chemicals (sulphuric acid, hydrochloric acid, caustic soda, ethanol etc) and Man Made Mineral Fibers (MMMFs). It is highly tactile in wet and dry conditions and dries soft. Manufactured by Southcombe using a proprietary formula, it is exclusive to Southcombe's range of gloves.

LINING

Seamless knitted KEVLAR® with glass-fibre core providing high levels of abrasion resistance and un-paralleled levels of cut/slash resistance (Level 5 when tested to EN388 standard). The lining is plated with a Viloft™ yarn to wick moisture away from the hand.



CUFF

Rib knitted NOMEX®/KEVLAR® (44%/54%) wristlet cuff with elastane (2%). PYROHIDE patches on palm side.

THREAD

Sewn throughout in NOMEX® thread.



- Manufactured to EN659:2003 + A1:2008 Protective Gloves for Structural Fire Fighting
- Water, fire and chemical resistant PYROHIDE cowhide leather
- NOMEX® Delta T fabric back with internal KEVLAR® patch across knuckles
- Seamless knitted cut resistant lining made from KEVLAR® with glass-fibre core and a Viloft yarn to wick moisture from the hand
- Level 4 dexterity
- 2 layer construction to enhance dexterity and to reduce heat stress
- 175 years of glove manufacturing heritage
- XXS/6, XS/7, S/8, M/9, L/10, XL/11, XXL/12, XXXL/13

Southcombe Brothers Ltd
Stoke-sub-Hamdon
Somerset TA14 6QD

Phone: +44 (0) 1935 823567
E-mail: sales@southcombe.com
www.southcombe.com

Firemaster Wildland

Wildland Fire-fighting Glove, Style No: SB02417A

CLAUSE	PROPERTY	TEST METHOD	MIN LEVEL REQUIRED	LEVEL ACHIEVED
3.1	General	EN420	Pass	Pass
3.2	Sizes	EN420 & EN659	Pass	Pass
3.3	Abrasion Resistance	EN388	Level 3	Level 3 (max 4)
3.4	Cut Resistance—Palm & Back	EN388	Level 2	Palm—Level 3 (max 5) Back—Level 5 (max 5)
3.5	Tear Resistance	EN388	Level 3	Level 4 (max 4)
3.6	Puncture Resistance	EN388	Level 3	Level 3 (max 4)
3.7	Burning Behaviour	EN407	Level 4	Level 4 (max 4)
3.8	Convective Heat—Palm & Back	EN367	Level 3	Level 4 (max 4)
3.9	Radiant Heat	EN6942	Pass	Pass (Level 2)
3.10	Contact Heat—Wet & Dry	EN702	Pass	Pass (Level 2)
3.11	Heat Resistance of Lining Material	ISO 17493	Pass	Pass
3.12	Heat Shrinkage	ISO 17493	Pass	Pass
3.13	Dexterity	EN420	Level 1	Level 4 (max 5)
3.14	Seam Breaking Strength	EN 139535-2	Pass	Pass
3.15	Time to Remove Gloves—Wet & Dry	ISO 15383	Pass	Pass
3.16	Resistance to Water Penetration	EN 20344	Optional	Level 4
3.17	Whole Glove Integrity	ISO 15383	Optional	N/A
3.18	Resistance to Liquid Chemical Penetration	EN 6530	Pass	Pass

GLOVE CARE AND MAINTENANCE

Gloves that are deemed non-repairable are to be disposed of when damaged. Gloves do not require the use of specialist solvent-based products for cleaning or maintenance and these should not be used under any circumstances. The design and materials used ensure that the user can maintain the gloves in hygienic condition. PYROHIDE is easy to clean and quick to dry. The leather also stays soft and dextrous after being wetted.

For best results follow this procedure:

- Produce a good lather in lukewarm water using mild detergent of neutral pH.
- Immerse the gloves and wash gently on your hands.
- Remove gloves and rinse thoroughly in clean water.
- Squeeze out all excess water from the fingers downwards and pull gently into shape.
- Hang to dry away from direct sunlight or heat.
- Wash gloves before they become too soiled.
- A sponge not a stiff brush is recommended to be used for ingrained grime.
- Gloves may be washed with articles of a similar colour provided the above instructions are followed.

